

## Reader End



Wiegand Reader



SecureLINX  
Wireless Unit



SL-WIE-REM  
Remote Unit



## Panel End

SecureLINX  
Wireless Unit



Wiegand Panel



SL-WIE-CEN  
Central Unit

